24IN Control
www.24inControl.com
(833) 247-7724 info@24inControl.com

Reconnect a camera to a wireless network if the router, equipment, or Wi-Fi settings change

If you get a new router or change the Wi-Fi credentials (name or password), you need to reconfigure the camera locally to connect to the new network

Access Point (AP) Method

1. Press and hold the WPS/Reset button on the back of the video device for 5 to 7 seconds until the LED starts flashing white.

2. Stay near the camera. Using your phone, tablet, or computer's Wi-Fi Settings, connect to the Wi-Fi network name that starts with either ALARM or ADC followed by (XX:XX:XX). (The numbers in parentheses are the last six digits of the video device's MAC address.)

3. On the same device (your phone, tablet or computer) open an Internet browser and enter 192.168.1.1 in the browser address bar. Press Enter.

4. Follow the on-screen instructions to connect the video device to your Wi-Fi network:

   4a. Click Scan for wireless networks.
   4b. Enter your WiFi Network's name (SSID) and the password.
   4c. Click OK and wait for the LED to turn solid green. If the camera's LED does not turn solid green, you most likely did not enter the correct Wi-Fi information in step 4b. Try again or reboot the video device retry this procedure.