

How to add a sensor from the IQ Panel

1. From the home screen, swipe down or tap the **top gray bar**
2. Tap:
 - **Settings** → **Advanced Settings**
3. Enter your **Installer Code**
 - Default is usually **1111** (or dealer code 2222)

2. Go to sensor enrollment

Navigate to:

- **Installation** → **Devices** → **Security Sensors** → **Auto Learn Sensor**

This puts the panel into **learn mode**

3. Trigger the sensor

- Insert the batteries, or pull out the batteries' tape, or if they are already installed, trip the sensor by separating the sensor from the magnet, or open the sensor's cover to send a Tamper signal, or separate the smoke detector from the ceiling bracket
- The panel should detect it and show a message like:
"Sensor #### is requesting to be added". Confirm that the DL # showing on the panel matches the one printed on the sensor
- Tap **OK** to confirm

4. Configure the sensor

Set the important fields:

- **Sensor Type** (door, motion, smoke, etc.)
- **Sensor Group** (how it behaves when armed)
- **Name** (e.g., "Front Door")
- Optional: chime, voice prompts

Then tap:

- **Add New** to save