



Enroll a Z-Wave device to IQ Panel 2/4

While setting up a Z-Wave network, keep in mind:

- Before adding devices to the network, make sure to put the devices in their final locations if possible. This way, the network can correctly identify the strongest communication pathway for each device.
- Always add devices closest to the panel first, and work outwards from there. Devices that have already been added can relay the panel's Add Mode signal to add farther devices to the network
- Make sure each device adds successfully before moving on to the next device. The panel, Partner Portal, or MobileTech app will indicate that a device has been added to the network.

It is recommended to perform the Clear process (see below) for each device prior to adding it - even if it is not on the network. This process clears the network data in the Z-Wave device allowing it to be added.

1. Clear the Z-Wave devices

1. From the home screen, swipe down from the top of the screen
2. Tap **Settings**.
3. Tap **Advanced Settings**.
4. Enter the installer code.
5. Tap **Installation**.
6. Tap **Devices**.
7. Tap **Z-Wave Devices**.
8. Tap **Clear**.
9. Trigger the device you intend to add (refer to the Z-Wave device's manual)
10. The panel beeps when a device has been deleted.
(repeat for more devices)

2 Enroll the Z-Wave device

1. From the home screen, swipe down from the top of the screen.
2. Press **Settings**.
3. Press **Advanced Settings**.
4. Enter the **Installer Code**.
5. Press **Installation**.
6. Press **Devices**

7. Press **Z-Wave Devices**
8. Press **Add**.
9. Trigger the device (refer to the Z-Wave device's manual) to add it to the panel's Z-Wave network.
10. When the device is added successfully, the panel will beep. Complete and approve the required steps on the panel

Troubleshooting:

If a device is not adding to the network, it may be required to delete the device's network data using the device deletion process before you can add it to the new network (some devices come from the factory with network data).