



XXXXXXXXXXXXXXXXXXXXXXXXXXXX

www.24inControl.com (833) 247-7724 ACO7650

Enroll a Z-Wave device to an Interlogix Simon XTi / XTi-5

While setting up a Z-Wave network, keep in mind:

- Before adding devices to the network, make sure to put the devices in their final locations if possible. This way, the network can correctly identify the strongest communication pathway for each device.
- Always add devices closest to the panel first, and work outwards from there. Devices that have already been added can relay the panel's Add Mode signal to add farther devices to the network
- Make sure each device adds successfully before moving on to the next device.
- Because a Z-Wave device may already have Z-Wave network information in its memory we recommend trying to clear the device first, before attempting to enroll

To Clear Z-Wave devices using the Interlogix Simon XTi / XTi-5 panel:

1. Press **Settings** (Gear Icon).
2. Press **Programming**.
3. Press **Interactive Services**.
4. Press **Z-Wave**.
5. Press **Remove Device**.
6. Trigger a device to clear its network data and remove it from the existing Z-Wave network.
7. The panel will beep when a device has been deleted.
8. It is required to re-enter Delete Mode to delete more devices.

To enroll Z-Wave devices using the Interlogix Simon XTi-5 panel:

1. Enter **System Programming**.
2. Press **Interactive Services**.
3. Press **Z-Wave**.
4. Press **Add Device**.
5. Trigger a device to add it to the network.
6. When a device is added successfully, the panel will beep.
7. It is required to re-enter Add Mode before triggering the next device.

Troubleshooting:

If a device is not adding to the network, it may be required to delete the device's network data using the device deletion process before you can add it to the new network (some devices come from the factory with network data).