



346 Rheem Blvd. #108A Moraga, CA 94556
www.24inControl.com (833) 247-7724 ACO7650

Enroll a Z-Wave device to an Interlogix Simon XT

- **Clear the device Z-Wave network data before attempting to enroll it. reason:**

A Z-Wave device may already have Z-Wave network information in its memory. It **MUST** be cleared before the device can be added to your system.

- Before adding devices to the network, make sure to put the devices in their final locations if possible. This way, the network can correctly identify the strongest communication pathway for each device.
- Always add devices closest to the panel first, and work outwards from there. Devices that have already been added can relay the panel's Add Mode signal to add farther devices to the network
- Make sure each device adds successfully before moving on to the next device.

To Remove (Clear) Z-Wave devices from the Interlogix Simon XT panel:

1. Scroll down to System Programming, then press **OK**.
2. Enter the installer code, then press **OK**.
3. Press to select **Interactive Services**.
4. Press to select **Z-Wave Setup**.
5. Press to select **Remove Z-Wave Device**.
6. **Trigger a device to clear its network data** and remove it from the existing Z-Wave network.
7. The panel will beep when a device has been deleted.
8. It is required to re-enter Delete Mode to delete more devices.

To enroll Z-Wave devices using the Interlogix Simon XT panel:

1. Scroll down to *System Programming*, then press **OK**.
2. Enter the installer code, then press **OK**.
3. Press to select **Interactive Services**.
4. Press to select **Z-Wave Setup**.
5. Press to select **Add Z-Wave Device**.
6. **Trigger a device** to add it to the network.
7. When a device is added successfully, the panel will beep.
8. It is required to re-enter Add Mode before triggering the next device.

Troubleshooting:

If a device is not adding to the network, it may be required to delete the device's network data using the device deletion process before you can add it to the new network (some devices come from the factory with network data).