


Smart Arming

Automated security that fits your lifestyle

Ensure a customer's home is secure while preventing false alarms and costly fines. Smart Arming remembers to arm and disarm a customer's security system at a pre-set time or based on their activity. Offer customers the full value of your service—security included—with as little hassle as possible.


Security on Schedule

- + Sleep with a calm mind by setting the system to auto-arm before bedtime.
- + Simplify morning routines by setting the system to auto-disarm when a hallway motion sensor is activated.
- + Easy setup ensures customers never have to remember to arm and disarm.
- + Host guests with varying schedules without the worry of triggering costly false alarms.



Configure Smart Arming from the app

1. Log into the customer app.
2. Tap Security System.



3. Tap Smart Arming. Follow the steps.

To configure Smart Arming using the customer website:

1. Log into the customer website.
2. On the Security System card, click the Smart Arming icon.
3. Click Smart Arming. (Note: Smart Arming can also be accessed from the Automation page) follow the setup.