



24^{IN}Control
www.24inControl.com

(833) 247-7724 info@24inControl.com

Reconnect a SkyBell Doorbell Camera if the wireless network or router changes

1. Delete and factory reset the Skybell

1. **To remove the SkyBell Doorbell Camera** from your account using the app: Login in to the app > click *Video* > click *Settings* (the gearwheel symbol at the upper-right corner) > Under Video Devices choose the doorbell > Scroll down and click *Remove This Device*.
2. **Factory reset** the SkyBell Doorbell Camera by pressing and holding the doorbell button until the LED starts blinking yellow. Wait for the SkyBell Doorbell Camera to reboot and enter Access Point (AP) mode. The LED blinks red and green to indicate it is in AP mode.

2. Reinstall the device on the desired network

1. Verify that the SkyBell Doorbell Camera is in AP mode. The LED should be blinking red and green.
2. Log in to the app.
3. Click Video (at the bottom) Click Settings (gearwheel symbol at the upper-left corner) .
4. Tap **Add Camera**.
5. Scroll down, choose any of the Skybell models. Follow the on-screen instructions to finish installing the SkyBell Doorbell Camera.